

INSTRUCTIONS

Pyramid Talking Alarm Clock

FORMAT: Clock is pyramid in shape with one big "Talk Button" at the top. Turn Clock over and on the bottom you will find a smooth compartment with small catch at the middle of the bottom. This is the battery compartment. Gently pry open the compartment by inserting your thumb nail under the catch and lifting off. Also at the bottom from left to right there are four 5 buttons - three of which slide and two tiny ones which need to be pressed to set hour and minute. Going from left to right the buttons are as follows:

- a. slide volume button (switch A) - at the lowest point its low volume, slid one notch to the middle is medium volume and slid one more notch it high volume.
- b. Slide alarm/time set button (switch B) - at the lowest point its time set, slid forward one notch at the highest point its Alarm set.
- c. Two tiny buttons. (Buttons C & D) The lower button is the minute set button. The higher button is the hour set button.
- d. Slide button (switch E) - Alarm on at the lower button setting and Alarm off at the higher button setting

TO INSERT BATTERIES:

1. OPEN THE BATTERY COVER
2. INSERT 3 AA BATTERIES INTO THE CLOCK
3. MAKE SURE POLARITIES ARE CORRECT.

TO SET THE TIME:

1. MOVE SWITCH B TO 'TIME SET' POSITION
2. PRESS 'HR' BUTTON TO INCREMENT HOURS
3. PRESS 'MIN' BUTTON TO INCREMENT MINUTES
4. ONCE DESIRED TIME IS REACHED, SLIDE SWITCH B TO CENTER POSITION

TO HEAR TIME ANNOUNCEMENTS:

1. PRESS THE 'TALK' BUTTON TO HEAR A PLEASANT FEMALE TIME ANNOUNCEMENT

TO SET THE ALARM TIME:

1. MOVE SWITCH B 'I'O 'ALM SET' POSITION
2. PRESS 'HR' BUTTON TO INCREMENT ALARM HOURS
3. PRESS 'MIN' BUTTON TO INCREMENT ALARM MINUTES
4. MOVE SWITCH B TO CENTER POSITION

TO TURN ON THE ALARM:

1. MOVE SWITCH C TO 'ALM ON' POSITION
2. THE ALARM WILL NOW SOUND AT THE ALARM TIME

*** TO SELECT THE ALARM SOUNDS:**

1. WITH SWITCH B IN CENTER POSITION, PRESS "HR"
(Third set of buttons going from left to right identified as buttons C & D) BUTTON TO SELECT THE ALARM SOUNDS, (DEE, CUCKOO OR ROOSTER)

TO TURN OFF THE ALARM:

1. WHEN ALARM IS SOUNDING, PRESS 'HR' OR 'MIN' BUTTONS TO CANCEL ALARM (Third set of buttons going from left to right identified as buttons C & D); ALARM CAN ALSO BE CANCELED BY MOVING SWITCH E TO 'ALM OFF' POSITION

*** TO ENTER SNOOZE MODE:**

1. WHEN ALARM IS SOUNDING, PRESS 'TALK' BUTTON (Located at the top of pyramid clock) TO ENTER SNOOZE MODE. ALARM WILL SOUND AFTER 10 MORE MINUTES

*** TO CHANGE THE VOLUME LEVEL:**

1. MOVE SWITCH A TO 'Vol High' (slide switch A pushed up at furthest position) FOR MAXIMUM VOLUME
2. MOVE SWITCH A TO 'Vol M' (slide switch A at middle position) FOR MEDIUM VOLUME
3. MOVE SWITCH A TO 'Vol Low' (slide switch A at lowest position) FOR LOW VOLUME

• NOTE

THE APPROXIMATE LIFE OF THE BATTERIES IS 1 YEAR. CHANGE BATTERIES WHEN THE DISPLAY LIGHTENS AND THE VOICE BEGINS TO WEAKEN.