## **INSTRUCTIONS**

## **Talking Alarm Clock and Temperature**

## Talking Clock (AUW009):

- Time reported with speech sounds (12hour/24 hour)
- Daily alarm (10 kinds of alarm to select)
- Snooze operation (Each time distance is 10 minute. Ringing 6 times)
- Temperature (-9.9°C  $\sim$  90°C)
- Two sets of time reported on the hour (CHMI is to report time on every o'clock sharp; CHM2 is to report time during 7 o'clock sharp AM~9 o'clock sharp PM)

## **Operation explanation:**

- 1. Normal display mode (press "MODE" to get into Time set mode)
  - TALKING: Reporting time and temperature
  - MIN/ALM: alarm sound select
  - HOUR/CHM: 12/24 hour time display selected mode
- 2. Time set mode: (press "mode" to get into Alarm set mode")
  - MINALM: (adjust minute)
  - HOUR/CHM: (adjust hour)
- 3. Alarm set mode(press "mode" to get into chime set mode)
  - MIN/ALM: (adjust minute)
  - HOUR/CHM: (adjust hour)
- 4. Chime set mode (press "mode" to get into normal display mode)
  - MIN/ALM: set alarm on/off
  - HOUR/CHM: set chime on/off

The set order is CHM off -> CHM1 on -> CHM2 on -> CHM off